


### Attention

- The remote control is powered by a 1.5 V carbon-zinc alkaline batteries of the standard LR03-AAA type.
- Do not place the remote control near to heat sources.
- Used batteries must be thrown in the battery bank.



### Warning!!!

The remote control replicates the functions on the control panel supplied with the hood. For a clearer understanding of these functions, please consult the instruction manual enclosed with the hood itself.

### Instructions for Activating the Wireless Remote Control

Before you can use your wireless remote control - you MUST first program and calibrate it to work with your range hood per the following instructions:

#### ON MODELS WITH GLASS TOUCH CONTROLS




- Switch off the light and the motor.
- Press the "24H"-key for about 5 seconds until the icons of activated functions will be lit.
- When releasing the key, the -symbol starts to flash, within 3 seconds press again the "24H"-key and the following will appear on the display:
  - the points under the motor LEDS .....!! are lit, the receiver of the remote control is **ACTIVATED**;
  - the points under the motor LEDS are unlit, the receiver of the remote control is **DISCONNECTED**.

#### ON ALL THE OTHER CONTROL SYSTEMS

- Switch off the motor and the lighting system.
- Ensure that no Filter saturation alarms are lit on the display (for further information please see Range-hood booklet).
- Keep on pressing the button for 5 second, you will see :
  - "TC" twice, to indicate the **ACTIVATION** of the REMOTE CONTROL RECEIVER;
  - "TC" once, to indicate the **DISCONNECTION** of the REMOTE CONTROL RECEIVER.

### Remote control functions for Swing (FSW)



KEY	PRESS*	FUNCTIONS (CLOSED PANEL)	FUNCTIONS (OPEN PANEL)
	Short	Opens the upper panel and sets the lights at the maximum intensity..	Switches the lights on/off.
	Short	No function	Sets the lights at an intermediate intensity or switches the lights off.
	Short	Opens the upper panel, switches on the motor at the latest selected speed.	Switches the motor on/off.
	Long	Opens the upper panel and switches on the motor at the third speed and the lights at the maximum intensity.	Switches off lights and motor and closes the upper panel.
	Short	No function	Decreases the speed at every short pressure.
	Short	No function	Increases the speed at every short pressure.
	Short	No function	Activates/deactivates the intensive speed.
	Short	No function	Activates / deactivates the Delay-function.
	Long	No function	Activates/deactivates the 24H-function.

\* The press is long when the key is pressed continuously for about 2 seconds

### Remote control functions with Touch Control

The following functions are valid for hoods with touch control except the SWING-range (FSW).



TASTO	PRESS*	FUNCTIONS	NOTE
	Short	Turns light on and off	
	Long	Switches on and off the secondary lighting system.	Available only for the hoods with a double lighting system.
	Short	Turns light on and off at reduced intensity.	Not available for the hoods belonging to the Kubus-range (FKU).
	Short	Switches the extractor motor on and off at the latest selected speed.	
	Short	Decreases the suction speed.	
	Short	Increases the suction speed.	
	Short	By pressing this key it is possible to activate the intensive speed from any previously selected speed. The intensive speed can be activated even when the motor is OFF. This speed has been timed. When the time is over the system activates automatically the latest selected speed.	
	Short	By pressing this key it is possible to set the delayed shutdown of the appliance to 30. It can be activated at any position, and it is deactivated by pressing the key again or by switching off the motor.	
	Long	By pressing this key it is possible to set up the motor to a suction speed at 100 m³/h for 10 minutes every hour.	

\* The press is long when the key is pressed continuously for about 2 seconds.

### Basic functions of the remote control

The following functions are valid for the hoods with electronic control.

TASTO	PRESS*	FUNCTIONS	NOTE
	Short	Turns light on and off	
	Long	Switches on and off the secondary lighting system.	Available only for the hoods with a double lighting system.
	Short	Turns light on and off at reduced intensity.	
	Short	Switches the extractor motor on and off at the latest selected speed.	
	Short	Decreases the suction speed.	
	Short	Increases the suction speed.	
	Short	By pressing this key it is possible to activate the intensive speed from any previously selected speed. The intensive speed can be activated even when the motor is OFF. This speed has been timed. When the time is over the system activates automatically the latest selected speed.	
	Short	By pressing this key it is possible to set the delayed shutdown of the appliance to 30. It can be activated at any position, and it is deactivated by pressing the key again or by switching off the motor.	
	Long	By pressing this key it is possible to set up the motor to a suction speed at 100 m³/h for 10 minutes every hour.	

\* The press is long when the key is pressed continuously for about 2 seconds.